SETUP SEQUENCE DOCUMENT FOR TIED SOFTWARE OF ELECTRIC TORQUE TESTER TNT_DSP

1. Provisions

Copy the following file on your PC.

・TNT_DSP_EN_v***.msi File（*** is the version）

2. TNT_DSP_EN_v***.msi File Installation

Double click the TNT_DSP_EN_v***.msi as follows and execute the installation.

TNT_DSP_EN_v***.msi

①

②

③

④

⑤

●About installing under standard user authority

The following screen will be displayed when installing.

Please enter the password of the administrator account and click "YES" to continue the installation.

● File Configuration

After installation is completed, the following folders and files are created in "C:¥TNT_DSP_EN".

+	TNT_DSP_EN.xla	:	Excel add-in software (TNT_DSP_EN)
+	Driver	:	Driver folder※
+	SETUP_CSV	:	Setting files※
+	FILE	:	Test result saving folder※

※

Do not change or remove the contents of Driver, SETUP_CSV and FILE folder because of a possibility that it may not operate properly.

3. USB driver Installation

After powered on DSP-10, insert the USB cable into the USB port of PC.

How to install the driver depends on your PC environment.

Please install according to PC environment.

Windows10

After powered on DSP-10, insert the USB cable into the USB port of PC and display "Device Manager".

●Administrator authority

Click "Update Driver" on the property screen,

Start the driver updating.

●Standard user authority

If logging in with standard user authority, please change to administrator authority at first. Then click "Update Driver" on the property screen and start the driver updating.

Click "Browse my computer for driver software" and proceed to the next.

Select "C:¥TNT_DSP_EN¥Driver" from "Browse" and click "Next"

After installation is completed, the above screen will be displayed. Please click "Close" to finish.

●Confirm COM Port

Execute the setting and confirmation of the COM Port No..

For selecting COM port No. at TNT_DSP startup, please check the COM port No. displayed on "Device Manager".

●Setting of COM Port

In case the COM Port No. is not in COM1~COM15, it is necessary to modify the COM Port No..

For Modifying the COM Port No., Clicking the USB Serial Port item on “Device Manager” to open the property Screen, then select the "Port Setting" Tag and “Advanced Setting”.

Above all, the Set-up of PC is over.

As regards the usage method of Tied software of electric torque tester “TNT_DSP”, refer to enclosed “Tied software of electric torque tester “TNT_DSP” User’s Manual”.

NIDEC DRIVE TECHNOLOGY CORPORATION

〈Web Page Information〉 Please scan the QR code or access the URL below.

Contact Us
https://www.nidec.com/en/nidec-drivetechnology/inquiry/

Sales Offices
https://www.nidec.com/en/nidec-drivetechnology/corporate/network/sales/

Copyright NIDEC DRIVE TECHNOLOGY Corporation. All Rights Reserved.

NIDEC DRIVE TECHNOLOGY CORPORATION
Nidec Shimpo Corporation change its company name to Nidec Drive Technology Corporation on April 1, 2023.